

TECHNICAL DOCUMENT

Receiving, Handling, and Storage

The proper receiving, handling and storage of windows and doors is critical to the performance of the products throughout their service life. Abuse of the products during these processes will affect their operation and appearance. Even if the effects are not immediately noticed, they could surface later in the life of the product. The following are precautions that need to be followed.

<u>Receiving</u>: Prior to receiving the shipment off the windows, ensure that there is an adequate location to receive the windows and enough manpower and equipment to off load the products.

- Depending on the glass configuration and the size of the windows, the windows may be extremely heavy. A loading dock or glass manipulator may be needed to offload the windows or doors without damaging them. Contact Graham Architectural to determine the weight of any windows that are over 40 square feet.
- Most trucking companies allow a 3 hour off-loading time, and will charge a detention fee if the truck is not offloaded within that time period. That should be considered when determining the location where the truck will be off-loaded and how much manpower will be needed to complete the process.
- Ensure that the storage location is close to the off-loading area. The product storage area must meet the requirements listed in the "Storage" section below.

Handling: HANDLE CAREFULLY - DO NOT DROP.

- It's recommended to use a glass manipulator for large or heavy units. Ensure that there is enough manpower to lift and maneuver the windows. Use glass cups when possible. Only use material handling equipment that will not damage the finish of the products.
- Be careful handling windows with pre-loaded sash or vents. Make sure pre-loaded sash or vents are fully locked prior to moving windows. Never have fingers or hands inside the operating area of a sash or vent.
- Do not use any of the hardware or grids for lifting or manipulating the window or door. Glazed products must always be transported vertically.

Storage:

- The storage location for any finished products must be cordoned off to prevent damage from other trades, such as moving equipment.
- Stack vertically and on their sills with adequate separation so window parts (including hardware) will not rub together, including any protruding hardware such as handles. All products should be stored on top of wood blocking to protect the finish and weather-strip. Blocking will also be needed between the frame and any object that can damage the window or door frame. Ensure that the products cannot be blown over by the wind, and limited to stacking of five (5) units before alternate support is given.
- Protect windows completely from moisture and dirt prior to installation. It is important that all windows that are not installed, are protected from direct contact with rain, snow, or ice so as to protect the finish and glazing of the product. If water gets into, and is retained in the glazing pocket it will cause the edge seal of the insulating glass to fail.



Receiving, Handling, and Storage

Storage (cont.):

- Storing the windows or doors in the building is preferred, as long as they are not in a high traffic area. If stored in a trailer, or under clear plastic, there must be adequate ventilation to prevent the temperature of the products from exceeding 110° F (43.3° C). Temperatures exceeding this threshold can damage the sealants in the insulating glass. Heat build can also cause stress fractures in the glass. If storing outside, the products must be covered in a manner that will prevent water from getting into the products, while allowing ventilation to prevent excessive temperature or humidity build-up.
- Construction debris and dirt within the frame will affect the operation of the window or door. Protect all products from paint, weld spatter, construction debris, cement, plaster, terrazzo, and other construction materials, which include, but are not limited to, alkali based materials or caustic cleaners. This must be removed immediately to prevent damage to the finish of the aluminum or to the clarity of the glass.
- If the windows have been wrapped in a transparent plastic protective wrap, this wrap cannot be on the product for more than 90 days from the date of manufacturing, otherwise, it will be very difficult to remove protective wrap from the window finish.